

# ***Hustler FasTrak Super Duty 36/42 Parts Manual***



**HUSTLER®**

•••••

*Excel Industries, Inc.*

•••••


*P.O. Box 7000*

•••

*Hesston, Kansas*

•

*67062-2097*



#### NOTICE OF REQUIREMENT OF SPARK ARRESTER MUFFLER

This equipment may create sparks that can start fires around dry vegetation. California Public Resources Code Section 4442.6 provides that it is unlawful to use or operate an internal combustion engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester maintained in effective working order. A spark arrester is a device constructed of nonflammable materials specifically for the purpose of removing and retaining carbon and other flammable particles over 0.0232 of an inch in size from the exhaust flow of an internal combustion engine that uses hydrocarbon fuels or which is qualified and rated by the United States Forest Service. Other states or federal areas may have similar laws. The Operator Should Contact Local Fire Agencies For Laws or Regulations Relating to Fire Prevention Requirements. THIS EQUIPMENT DOES NOT HAVE A SPARK ARRESTER AND YOU SHOULD CONTACT YOUR AUTHORIZED DEALER FOR THE PURCHASE OF A SPARK ARRESTER.

Inspect spark arrester daily; replace every 500 hours or as needed.

The Engine Owner's Manual provides information regarding the U.S. Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance and warranty.

Keep Engine Owner's Manual with your unit. Should the Engine Owner's Manual become damaged or illegible, replace immediately. Replacements may be ordered per the information found in the Product Information section of the owner's manual.

---

# Table of Contents

## General Information

Service Literature . . . . .	1-1
Options Available From Your Dealer. . . . .	1-1
Using this manual . . . . .	1-1
Hardware Description Codes & Abbreviations . . . . .	1-2
Standard Torques . . . . .	1-2

## Section 2

Frame . . . . .	2-2
Footrest. . . . .	2-4

## Section 3

Hydraulic System . . . . .	3-2
Transmission Service Parts . . . . .	3-8
Steering. . . . .	3-10
Park Brake . . . . .	3-12

## Section 4

Wheel & Tire . . . . .	4-2
Wheel & Tire Breakdown . . . . .	4-4

## Section 5

FX600V Engine. . . . .	5-2
FX600V Engine Service Parts. . . . .	5-6
Engine Guard . . . . .	5-8
EVAP System . . . . .	5-10
Fuel System . . . . .	5-12
Fuel & EVAP Service Parts. . . . .	5-14

## Section 6

Battery. . . . .	6-2
Instrument Panel. . . . .	6-4

## Section 7

36" Service Deck. . . . .	7-2
36" Deck Pulleys & Spindles. . . . .	7-4
36" Deck . . . . .	7-6
42" Service Deck. . . . .	7-8
42" Deck Pulleys & Spindles. . . . .	7-10
42" Deck . . . . .	7-12
Deck Lift . . . . .	7-14
Deck Mounting . . . . .	7-16

## Section 8

Seat. . . . .	8-2
ROPS . . . . .	8-6

Index . . . . .	i-1
-----------------	-----





---

# General Information

*This Manual covers Hustler FasTrak Super Duty 36" & 42" models **930818 & 930826.***

---

## **Service Literature**

PART NO.	DESCRIPTION
603519	OPERATOR'S MANUAL
114191	WARRANTY STATEMENT

---

## **Options Available From Your Dealer**

PART NO.	DESCRIPTION
600213	FLEX FORK (42" MOWER)
107696	HITCH KIT
107654	MULCH KIT (36" & 42" MOWERS)

***Note:** When ordering parts, you must use the part number as shown for each part, not the index number. Always give the model and serial number to your parts and service representative.*

***Note:** Items sold in bulk such as seals and hoses are sold by the foot.*

---

## **Using this manual**

*This manual is part of a service package for the Hustler mowers. Use of this manual in conjunction with other Hustler mower and component manuals will provide the information necessary to service and maintain Hustler mowers.*

*This Parts Manual provides a complete parts listing for the unit. Use this manual when ordering parts. Illustrations used were current at the time of printing, but subsequent production changes may cause your machine to vary slightly in detail. Excel Industries, Inc. reserves the right to redesign and change the machine as deemed necessary, without notification. If a change has been made to your machine which is not reflected in this parts manual, see your Hustler dealer for current information and parts.*

*The Service Manual is a service guide for use by Service Technicians. It provides the necessary information needed to perform normal maintenance requirements on these units.*

*The Operator's Manual provides fundamental operational information and operational safety that is needed when operating the mower.*

*The component manuals are furnished by the various manufacturers to be used for the troubleshooting and servicing of their products.*

---

## **Hardware Description Codes & Abbreviations**

*The following codes are used throughout this parts manual. Refer to this list when ordering parts.*

ABBREVIATION	DESCRIPTION	ABBREVIATION	DESCRIPTION
CB	CARRIAGE BOLT	MB	MACHINE BUSHING
CE	CLEVIS PIN	MS	MACHINE SCREW
CN	CLIP NUT	NT	NUT
CP	COTTER PIN	SC	SELF TAPPING CAP SCREW
CS	CAP SCREW	SH	SOCKET HEAD
CW	CUP WASHER	SB	SHOULDER BOLT
FDRW	FENDER WASHER	SS	SET SCREW
FW	FLAT WASHER	OD	OUTSIDE DIAMETER
HX	HEX HEAD	ID	INSIDE DIAMETER
LW	LOCK WASHER		

---

## **Standard Torques**

*The following chart lists the standard torque values for the threaded fasteners found in this manual. Torque all cap screws, nuts and set screws to these values unless a different torque is shown in the Notes section next to the fastener.*


SIZE	FT-LBS	N-M	SIZE	FT-LBS	N-M
.250	8.2	11.1	M3	1	1.3
.312	17	23	M4	2.2	3
.375	30	40	M5	4.5	6.1
.438	48	65	M6	7.7	10.4
.500	73	99	M8	18.5	25
.562	105	143	M10	37	50
.625	145	200	M12	64	87
.750	260	350	M14	80	108.5
.875	420	565	M16	160	215
1.00	625	850	M20	320	435
			M24	555	750

---

## Section 2

Frame .....	2-2
Footrest .....	2-4

# Frame



---

## **Frame**

INDEX NO.	PART NO.	QTY	DESCRIPTION
1	551085	1	36" FRAME
	551086	1	42" FRAME
2	785220	1	RS STEERING DECAL
3	785139	1	LS STEERING DECAL
4	727172	1	MADE IN U.S.A.
5	N/A	3	SERIAL NO PLATE TURF
6	600899	1	PUMP BELT WARNING DECAL
7	791848	1	FUEL INDICATOR DECAL
8	601967	1	ENGINE COMPARTMENT DECAL
9	602041	1	HOT DECAL
10	808493	8	RIVET NUT, 3/8-16 THREAD
11	603542	1	TOW VALVE DECAL
12	601421	1	FASTRAK SUPER DUTY ID DECAL
13	601993	1	SAFE OPERATION DECAL
14	808485	1	RIVET NUT, 5/16-18 THREAD
15	785154	1	DECK HEIGHT DECAL
16	602407	1	HUSTER ID DECAL


---

### **NOTES:**

1. In the event the serial number tag becomes damaged or illegible, please contact your dealer to order a replacement.
2. EPA compliance plate.
3. Patent numbers plate.

---

## **Footrest**



---

## **Footrest**

INDEX NO.	PART NO.	QTY	DESCRIPTION
1	551087	1	FLOOR PLATE (WITH STEP TREADS)
2	601986	2	LOWER STEP TREAD
3	781880	5	BUMPER, .500 X 1.00 X .312
4	785485	2	STEP TREAD, UPPER

---

### **NOTES:**






---

## Section 3

Hydraulic System . . . . .	3-2
Transmission Service Parts . . . . .	3-8
Steering . . . . .	3-10
Park Brake . . . . .	3-12

# Hydraulic System



---

## **Hydraulic System**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	710087	8	CS .312-18 X 2.500 HX G5
2	768523	12	FW .343 X .687 X .051/.080H
3	603486	2	TOW LINK ROD
4	601503	2	CB .250-20 X .625 ZNYC
5	111617	1	RS TOW VALVE BRACKET
	111616	1	LS TOW VALVE BRACKET (NOT SHOWN)
6	041988	2	SPRING
7	768515	10	FW .281 X .625 X .051/.080H
8	068551	4	NT .250-20 HXZY NL
9	601162	2	IDLER PULLEY
10	028118	5	FW .625 X 1.00 X .134 ZNYC
11	025007	2	CS .625-11 X 1.750 HX G5
12	602253	1	BELT
13	600965	1	CS .375-16 X 8.50 G5 HX ZN
14	767954	2	FW .406 X .812 X .060 SAE
15	601197	1	LH TRANSMISSION
16	601196	1	RH TRANSMISSION
17	034272	8	NT .312-18 HX G5 ZNYC
18	086660	1	NT .375-16 HXZY NL
19	107633	1	SPACER
20	114974	2	TRANSMISSION GUARD
21	603617	2	SC .250-20 X 50 HX FL STP

---

### **NOTES:**

1. Torque to 10 ft-lbs.
2. Torque to 17 ft-lbs.

# **Hydraulic System**



---


## **Hydraulic System**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
20	601983	1	CS .625-11 X 2.25 HX G5 ZY
21	111079	1	PUMP IDLER
22	036384	1	SPRING 1/4 COIL PL 1.23
23	601398	1	IDLER SPACER
24	786848	1	IDLER PULLEY
25	016972	1	NT .625-11 HX G5 ZNYC
26	781567	1	NT .500-13 HX G8 ZY NL
27	602026	2	BEARING DISC
28	602025	1	BUSHING
29	017616	1	CS .500-13 X 1.750 HX G5

---

### **NOTES:**

## **Hydraulic System**



---

## **Hydraulic System**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
30	794644	2	GROMMET
31	600759	1	OVERFLOW TANK (WITH CAP)
32	601474	4	SPRING CLAMP
33	603476	1	FORMED HOSE, RS TRANSMISSION TO TANK
34	787713	8.5"	HOSE, 0.50", LS TRANSMISSION TO TANK
35	055939	2	CS .250-20 X .750 HX G5
36	601219	2	FTG, 90 - 9/16 SAE
37	601118	2	CN .250-20 X .19 MAX THK
38	600767	1	OVERFLOW TANK CAP

---

### **NOTES:**

---

## **Transmission Service Parts**





---


## **Transmission Service Parts**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	601941	1	FAN/PULLEY KIT
2	601221	1	BRAKE ARM
3	600972	1	RETAINING CLIP
4	600976	1	OIL FILTER
5	600975	1	LS FILTER GUARD
	600974	1	RS FILTER GUARD (NOT SHOWN)
6	600970	1	4 BOLT HUB KIT

---

### **NOTES:**

# **Steering**



---


## **Steering**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	110370	2	STEERING BAR W/ GRIP
2	705178	2	CS .375-16 X 1.750 HX G5
3	080655	4	CS .375-16 X 1.500 HX G5
4	767954	12	FW .406 X .812 X .060 SAE
5	054502	4	NT .375-16 HX GRD 5 ZNY
6	781153	4	BUSHING
7	784439	2	LOCK COLLAR, 0.757 ID
8	603477	1	STEER BOX, RS
	603478	1	STEER BOX, LS (NOT SHOWN)
9	603483	1	STEER LEVER, RS
	603484	1	STEER LEVER, LS (NOT SHOWN)
10	023655	4	NT .312-24 HX NL ZN
11	768523	15	FW .343 X .687 X .051/.080H
12	086660	2	NT .375-16 HXZY NL
13	600221	2	STEERING DAMPER
14	781922	4	BALL STUD
15	029876	2	LW .312 INT-EXT TOOTH
16	034272	2	NT .312-18 HX G5 ZNYC
17	600981	2	PUMP ROD
18	110014	1	PIVOT TUBE
19	034280	1	CS .312-18 X .750 HX G5
20	016832	2	NT .312-18 HXFLK ZNYC
21	601425	1	CONNECTOR BODY
22	601426	1	CAP LOCK

---

### **NOTES:**

## **Park Brake**



---

## **Park Brake**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	781211	2	PUSH BUTTON SWITCH
2	601822	2	NUT PLATE
3	086660	2	NT .375-16 HXZY NL
4	767954	4	FW .406 X .812 X .060 SAE
5	063198	4	CS 10-24 X .750 HXFLK ZN
6	005108	2	CS .375-16 X 3.50 HX G5 Z
7	765339	4	BUSHING
8	768523	8	FW .343 X .687 X .051/.080H
9	023655	4	NT .312-24 HX NL ZN
10	781583	2	BRAKE ROD ASSEMBLY
11	058842	4	NT .250-28 HX JAM ZNYC
12	768515	10	FW .281 X .625 X .051/.080H
13	114628	1	RS BELLCRANK
	114629	1	LS BELLCRANK (NOT SHOWN)
14	601201	2	BALL JNT, W/ STUD 1/4-28
15	603485	2	BRAKE ROD
16	055939	2	CS .250-20 X .750 HX G5
17	108588	1	RS ACT FST BRACKET
	108598	1	LS ACT FST BRACKET (NOT SHOWN)
18	024927	2	NT .250-20 HX GR.5 ZNYC
19	061572	2	SPRING
20	601211	2	OVERTRAVEL SPRING
21	068551	2	NT .250-20 HXZY NL

---

### **NOTES:**




---

## Section 4

Wheel & Tire . . . . .	4-2
Wheel & Tire Breakdown . . . . .	4-4

## Wheel & Tire





---

## **Wheel & Tire**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	600676	2	TIRE/WHEEL 20 X 8-10
	600668	2	TIRE/WHEEL 20 X 10-10
2	061077	8	WHEEL NUT
3	705954	2	CS .500-13 X 1.250 HX G5 ZN
4	344267	6	FW .510 X 2.15 X .187 SPL
5	712976	2	FW .531 X 1.375 X .125 ZNY
6	784223	4	BEARING
7	784603	2	SPACER
8	061101	2	NT .750-10 HXZY NL
9	025296	4	FW .760 X 1.625 X .08 ZNYC
10	366625	2	FORK
11	786731	2	CS .750-10 X 8.00 HX GR5
12	786061	2	TIRE/WHEEL 13 X 500
13	781567	2	NT .500-13 HX G8 ZY NL
14	788166	2	ANTI-SCALP WHEEL (WITH HARDWARE)
15	781708	2	CS .500-13 X 4.250 HX G5
16	767962	4	FW .531 X 1.063 X .090 SAE
17	031997	2	ANTI-SCALP WHEEL
18	053199	2	NT .500-13 HX JAM ZNYC


---

### **NOTES:**

1. Torque to 65-75 ft-lbs.
2. Tire/wheel usage:

TIRE/WHEEL	USED ON
600676	930818
600668	930826

## **Wheel & Tire Breakdown**



---

## **Wheel & Tire Breakdown**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	600692	1	TIRE 20 X 8-10 (USED WITH 36" DECK)
	600684	1	TIRE 20 X 10-10 (USED WITH 42" DECK)
2	600718	1	WHEEL 10 X 7 (USED WITH 36" DECK)
	600700	1	WHEEL 10 X 7 (USED WITH 42" DECK)
3	019521	1	TIRE VALVE
4	747402		TIRE 13 X 5
5	786079	1	WHEEL
6	015511	1	GREASE FITTING
7	786103	2	WHEEL BEARING

---

### **NOTES:**




---

## Section 5

FX600V Engine . . . . .	5-2
FX600V Engine Service Parts . . . . .	5-6
Engine Guard. . . . .	5-8
EVAP System . . . . .	5-10
Fuel System. . . . .	5-12
Fuel & EVAP Service Parts . . . . .	5-14

# **FX600V Engine**



---

## **FX600V Engine**



INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	N/A	1	ENGINE, KAW FX600V
2	029876	1	LW .312 INT-EXT TOOTH
3	796219	1	NEGATIVE BATTERY CABLE
4	768523	7	FW .343 X .687 X .051/.080H
5	720516	1	CS M8 X 1.25 X 16 G10.9 HX
6	744276	1	POSITIVE BATTERY CABLE
7	602999	1	MUFFLER
8	706531	1	GM 1.12 X 1.75 X 1.37 X .12
9	603289	1	GM, 2.25ID X 3.0OD X 2.5GD
10	034272	4	NT .312-18 HX G5 ZNYC
11	767954	4	FW .406 X .812 X .060 SAE
12	602580	4	CS .375-16 X 1.25 HXG5 P85
13	114648	1	MUFFLER SHIELD
14	016253	2	CB .312-18 X .750 FUL ZN
15	036236	2	CS .312-18 X 1.000 HX G5
16	113946	1	CLUTCH ANCHOR
17	712372	1	KEY 1/4 SQ X 0.66 LG
18	603255	1	PULLEY
19	603545K	1	CLUTCH KIT
20	602680	1	FW .453 X 1.12 X .119 HRD
21	785659	1	CS .437-20 X 2.50 HXG5
22	791251	1	CLUTCH HARNESS PIGTAIL

---

### **NOTES:**

1. Torque to 45-48 ft-lbs. Replace (do not reuse) capscrew if removed or loosened. Use only hand tools to install this fastener.
2. Supplied with engine.
3. Part of wire harness.
4. Part of clutch.
5. Torque the bolt to 30 ft-lbs. Replace (do not reuse) the capscrew if removed or loosened. Use only hand tools to install this fastener.

## **FX600V Engine**







---

## **FX600V Engine**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
23	000323	2	HOSE CLAMP
24	000331	4	WIRE TIE, SMALL/SHORT
25	015818	17"	1/4" FUEL LINE
26	603326	29"	3/16" VAPOR LINE
27	603112	2	CLAMP, 3/16"
28	796524	1	OIL DRAIN VALVE


---

### **NOTES:**

FUEL & VAPOR LINE LENGTHS		
	17"	TANK TO FILTER (FUEL)
	29"	ENGINE TO VACUUM BREAKER (VAPOR)

---

## **FX600V Engine Service Parts**



---

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	761726		MAIN AIR FILTER ELEMENT
2	068478		IN-LINE FUEL FILTER
3	602581		KAWASAKI ENGINE OIL FILTER


---

### **NOTES:**

---

**This page intentionally left blank.**

## **Engine Guard**



---


## **Engine Guard**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	114860	1	RS ENGINE GUARD
2	114631	1	ENGINE GUARD
3	114861	1	LS ENGINE GUARD
4	808493	4	3/8-16 THREAD RIVET NUT
5	767954	10	FW .406 X .812 X .060 SAE
6	036244	4	CS .375-16 X 1.000 HX G5
7	052860	6	CS .375-16 X 1.25 HX G5 ZN

---

### **NOTES:**

# **EVAP System**



---

## **EVAP System**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	015818	89"	1/4" FUEL LINE
2	000323	11	HOSE CLAMP
3	603025	1	PLASTIC TEE, 1/4"
4	047456	2	GM .750 X .188 X 1.00 X .12
5	036236	4	CS .312-18 X 1.000 HX G5
6	768523	4	FW .343 X .687 X .051/.080H
7	016832	4	NT .312-18 HXFLK ZNYC
8	000398	4	LOOP CLAMP
9	603024	1	VACUUM BREAKER

---

### **NOTES:**

VAPOR LINE LENGTHS		
<b>A</b>	6"	LEFT TANK TO TEE (VAPOR)
<b>B</b>	19"	TEE TO VACUUM BREAKER (VAPOR)
<b>C</b>	24"	RIGHT TANK TO VACUUM BREAKER (VAPOR)

# **Fuel System**





---



## **Fuel System**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
10	603088	1	LS TANK FENDER
11	603089	1	RS TANK FENDER
12	602916	2	RATCHETING GAS CAP, 3.5"
13	745059	1	FUEL VALVE 3-WAY
14	767954	6	FW .406 X .812 X .060 SAE
15	055822	6	CS .375-16 X .750 HX G5
16	781880	2	BUMPER

---


### **NOTES:**

1. Torque to 20 ft-lbs.

FUEL LINE LENGTHS		
	28"	LEFT TANK TO VALVE (FUEL)
	12"	RIGHT TANK TO VALVE (FUEL)

---

## **Fuel & EVAP Service Parts**



---

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	603158	1	ROLLOVER VALVE & GROMMET
2	601527	1	SUCTION HOSE
3	785295	1	GROMMET
4	603161	1	VACUUM BREAKER FILTER

---


### **NOTES:**

---

## Section 6

Battery . . . . .	6-2
Instrument Panel . . . . .	6-4

# **Battery**



---


## **Battery**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	714618	2	CS .312-18 X 4.000 HX G5
2	768523	2	FW .343 X .687 X .051/.080H
3	601212	1	BATTERY CABLE SUPPORT
4	348417	1	BATTERY CLAMP STRAP
5	029868	4	LW .250 INT-EXT TOOTH Z
6	055939	2	CS .250-20 X .750 HX G5
7	024927	2	NT .250-20 HX GR.5 ZNYC
8	771428	1	RED BATTERY CABLE BOOT
9	603289	1	GROMMET 2.25"
10	601069	2	CN .312-18 X .200 MAX THK
11	794644	1	GROMMET 1.50"

---

### **NOTES:**

# **Instrument Panel**



---

## **Instrument Panel**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	786657	1	CHOKE CABLE
2	785808	1	KEY ASSEMBLY
3	776476	1	PTO SWITCH
4	045898	1	IGNITION SWITCH
5	712257	1	RED INDICATOR LIGHT
6	602468	1	INSTRUMENT PANEL DECAL
7	603334	1	WIRE HARNESS
8	769166	1	HOUR METER
9	601098	4	CB 10-24 X .500 ZYNC
10	059832	4	NT #10-24 HX NL ZN
11	778365	1	THROTTLE CABLE
12	704932	2	FW .219 X .500 X .048 ZNYC
13	055947	3	CS .250-20 X .500 HX G5
14	768515	3	FW .281 X .625 X .051/.080H
15	550446	1	INSTRUMENT PANEL (WITH DECAL)
16	000331	3	WIRE TIE, SMALL/SHORT
17	114052	1	CLUTCH CONNECTOR REPAIR KIT

---

### **NOTES:**

1. Part of wiring harness.







---

## Section 7

36" Service Deck . . . . .	7-2
36" Deck Pulleys & Spindles . . . . .	7-4
36" Deck . . . . .	7-6
42" Service Deck . . . . .	7-8
42" Deck Pulleys & Spindles . . . . .	7-10
42" Deck . . . . .	7-12
Deck Lift. . . . .	7-14
Deck Mounting. . . . .	7-16

## **36" Service Deck**



---


## **36" Service Deck**

INDEX NO.	PART NO.	QTY	DESCRIPTION
1	550956	1	36" DECK (WITH DECALS AND HARDWARE)
2	601069	4	CN .312-18X.200 MAX THK
3	036244	2	CS .375-16 X 1.000 HX G5
4	767954	4	FW .406 X .812 X.060 SAE
5	114645	2	HANGER
6	054502	2	NT .375-16 HX GRD 5 ZNY
7	603548	1	BELT ROUTING DECAL
8	793513	1	36" DECK ID DECAL
9	601837	2	DECK DANGERS DECAL
10	601624	1	DISCHARGE CHUTE DECAL
11	601892	1	THROWN OBJECTS DECAL

---

### **NOTES:**

# 36" Deck Pulleys & Spindles



---

## **36" Deck Pulleys & Spindles**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	025007	2	CS .625-11 X 1.750 HX G5
2	347443	2	DECK BELT IDLER GUIDE
3	028118	2	FW .625 X 1.00 X .134 ZNYC
4	603057	2	DUST SHIELD WITH OFFSET
5	781856	2	IDLER PULLEY, NHI 5.0"
6	600296	1	DECK IDLER SPACER
7	114433	1	IDLER SLIDE
8	036384	1	SPRING 1/4 COIL PL 1.23
9	259812	1	CHAIN
10	601434	2	UHMW IDLER SLIDE
11	784199	6	CS .312-18 X 1.250 FLT SH
12	781872	2	CS .625-11 X 1.25 HX G5 Z
13	782474	2	CW .631 X 2.250 X .187 PNT
14	796656	1	PULLEY, 5.62 EOD, A-SEC
15	796664	1	PULLEY, 3.75 EOD, A-SEC
16	054502	8	NT .375-16 HX GRD 5 ZNY
17	767954	16	FW .406 X .812 X .060 SAE
18	005116	8	CS .375-16 X 1.375 HX G5
19	783506	2	BLADE SPINDLE
20	768523	10	FW .343 X .687 X .051/.080H
21	058776	6	NT .312-18 HXZY NL
22	788166	1	ANTI-SCALP WHEEL (WITH HARDWARE)
23	781567	1	NT .500-13 HX G8 ZY NL
24	034272	2	NT .312-18 HX G5 ZNYC
25	797365	2	DECK PULLBAR
26	034280	2	CS .312-18 X .750 HX G5
27	322974	2	PULLBAR PIN
28	781708	1	CS .500-13 X 4.250 HX G5
29	767962	2	FW .531 X 1.063 X .090 SAE
30	031997	1	ANTI-SCALP WHEEL
31	053199	1	NT .500-13 HX JAM ZNYC

---

### **NOTES:**

1. Torque to 118 ft-lbs.
2. Torque to 30 ft-lbs.

## **36" Deck**



---

## **36" Deck**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	601806	1	DISCHARGE CHUTE
2	601824	1	TORSION SPRING
3	100875	1	RS PULLEY COVER
4	601843	1	CHUTE PIN
5	100867	1	LS PULLEY COVER
6	600726	1	BELT, A 114.3" EL
7	086660	3	NT .375-16 HXZY NL
8	767954	2	FW .406 X .812 X .060 SAE
9	112877	1	CHUTE BRACKET
10	768523	4	FW .343 X .687 X .051/.080H
11	034280	4	CS .312-18 X .750 HX G5
12	600900	1	BLADE, F13.75"-L-F-CW
13	600901	1	BLADE, F20.50"-L-F-CW
14	782474	2	CW .631 X 2.250 X .187 PNT
15	781872	2	CS .625-11 X 1.25 HX G5 Z

---

### **NOTES:**

1. Torque to 118 ft-lbs.
2. Do not torque nut; the discharge chute must pivot freely.

## **42" Service Deck**





---


## **42" Service Deck**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	550957	1	42" DECK (WITH DECALS & HARDWARE)
2	601069	4	CN .312-18 X .200 MAX THK
3	603548	1	BELT ROUTING DECAL
4	793521	1	42" DECK ID DECAL
5	794503	1	DECK STEP TREAD
6	601837	2	DECK DANGERS DECAL
7	601624	1	DISCHARGE CHUTE DECAL
8	601892	1	THROWN OBJECTS DECAL

---

### **NOTES:**

## 42" Deck Pulleys & Spindles



---

## **42" Deck Pulleys & Spindles**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	025007	2	CS .625-11 X 1.750 HX G5
2	347443	2	DECK BELT IDLER GUIDE
3	028118	2	FW .625 X 1.00 X .134 ZNYC
4	603057	2	DUST SHIELD WITH OFFSET
5	781856	2	IDLER PULLEY, NHI 5.0"
6	784199	6	CS .312-18 X 1.250 FLT SH
7	601434	2	UHMW IDLER SLIDE
8	600296	1	DECK IDLER SPACER
9	114433	1	IDLER SLIDE
10	036384	1	TENSION SPRING
11	259812	1	CHAIN, 13 LINK
12	781872	2	CS .625-11 X 1.25 HX G5 Z
13	782474	2	CW .631 X 2.250 X .187 PNT
14	796656	2	PULLEY, 5.62 EOD, A-SEC
15	054502	8	NT .375-16 HX GRD 5 ZNY
16	767954	16	FW .406 X .812 X .060 SAE
17	783506	2	BLADE SPINDLE
18	005116	8	CS .375-16 X 1.375 HX G5
19	768523	10	FW .343 X .687 X .051/.080H
20	058776	6	NT .312-18 HXZY NL
21	322974	2	PULLBAR PIN
22	034280	2	CS .312-18 X .750 HX G5
23	788166	2	ANTI-SCALP WHEEL (WITH HARDWARE)
24	781567	2	NT .500-13 HX G8 ZY NL
25	034272	2	NT .312-18 HX G5 ZNYC
26	797365	2	DECK PULLBAR
27	781708	1	CS .500-13 X 4.250 HX G5
28	767962	2	FW .531 X 1.063 X .090 SAE
29	031997	1	ANTI-SCALP WHEEL
30	053199	1	NT .500-13 HX JAM ZNYC

---

### **NOTES:**

1. Torque to 118 ft-lbs.
2. Torque to 30 ft-lbs.

## **42" Deck**



---

## **42" Deck**


INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	601806	1	DISCHARGE CHUTE
2	601824	1	TORSION SPRING
3	086660	3	NT .375-16 HXZY NL
4	767954	2	FW .406 X .812 X .060 SAE
5	112877	1	CHUTE BRACKET
6	100875	1	RS PULLEY COVER
7	601843	1	CHUTE PIN
8	105155	1	LS PULLEY COVER
9	793893	1	BELT, A 127.3" EL
10	768523	4	FW .343 X .687 X .051/.080H
11	034280	4	CS .312-18 X .750 HX G5
12	600901	2	BLADE, F20.50"-L-F-CW
13	782474	2	CW .631 2.250 X .187 PNT
14	781872	2	CS .625-11 X 1.25 HX G5 ZN

---

### **NOTES:**

1. Torque to 118 ft-lbs.
2. Do not torque nut; the discharge chute must pivot freely.

## **Deck Lift**



---


## **Deck Lift**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	348318	1	STOP HANDLE
2	348284	1	HEIGHT ADJ STOP
3	781229	1	CE .750 X 2.25 X 1.75 HEAD
4	756270	1	CS .312-18 X 1.50 FLTHR G
5	034272	1	NT .312-18 HX G5 ZNYC
6	348458	1	DECK LEVELER YOKE
7	781831	1	CS .437-14 X 1.750 FULTH
8	360131	2	DECK LIFT CHAIN
9	704643	12	NT .437-14 HX FLG ZN
10	767962	6	FW .531 X 1.063 X .090 SAE
11	015495	3	GREASE FITTING STRAIGHT
12	784488	1	DECK LIFT INDICATOR
13	025296	4	FW .760 X 1.625 X .08 ZNYC
14	781294	5	E CLIP 1.00 X .625 X .05
15	782995	1	DECK LIFT SPRING
16	055749	5	CS .437-14 X 1.750 HX G5
17	334045	1	DECK LIFT LINK

---

### **NOTES:**

## **Deck Mounting**





---

## **Deck Mounting**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
18	781567	2	NT .500-13 HX G8 ZY NL
19	017616	2	CS .500-13 X 1.750 HX G5

---

### **NOTES:**




---

## Section 8

Seat .....	8-2
ROPS.....	8-6

# Seat



---


## **Seat**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	792226	1	SEAT
2	036236	2	CS .312-18 X 1.000 HX G5
3	768523	9	FW .343 X .687 X .051/.080H
4	017129	4	FW .440 X 1.000 X .083 ZNY
5	704635	2	NT .437-20 HX GR5 ZNYC
6	754101	2	CS .437-20 X 1.250 G5 ZNY
7	603489	1	SEAT BELT
8	114641	1	SEAT BELT CROSS BAR
9	551088	1	SEAT PAN (WITH DECALS)
10	034280	4	CS .312-18 X .750 HX G5
11	034272	3	NT .312-18 HX G5 ZNYC
12	080655	2	CS .375-16 X 1.50 HX G5
13	767954	9	FW .406 X .812 X .060 SAE
14	793851	2	COMPRESSION SPRING 1.25 X 4.00 X .188
15	086660	4	NT .375-16 HXZY NL
16	036244	2	CS .375-16 X 1.000 HX G5
17	601815	1	BATTERY WARNINGS DECAL
18	005108	1	CS .375-16 X 3.50 HX G5 Z
19	783910	1	TORSION SPRING
20	603101	1	SEAT LATCH
21	754358	1	SB .375 X .375 SH .312-18
22	043570	1	HOSE CLAMP

---

### **NOTES:**

## **Seat**




---

## **Seat**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	793315	1	SEAT SWITCH
2	797456	1	ARMREST KIT ROUND
3	797464	1	ARMREST ASSEMBLY, LS ROUND (WITH BRACKET)
4	797472	1	ARMREST ASSEMBLY, RS ROUND (WITH BRACKET)
5	797480	1	MOLDED ROUND ARMREST
6	793273	1	ARMREST STOP ASSEMBLY

---

### **NOTES:**





---

# **ROPS**

INDEX NO.	PART NO.	QTY.	DESCRIPTION
1	603696	1	ROPS KIT (WITH DECALS, SEATBELT & HARDWARE)
2	601470	2	HAND KNOB
3	601471	2	LYNCH PIN W/ LANYARD
4	077859	1	CS .500-13 X 3.250 HX G5
5	602647	1	ROPS STOP
6	023317	6	NT .500-13 UNT LK G8 ZN
7	721910	5	CS .500-13 X 2.75 HX G5 Z
8	767962	8	FW .531 X 1.063 X .090 SAE
9	601635	2	ROPS DECAL

---

## **NOTES:**



# Numerical Index

Part No.	Page No.	Part No.	Page No.	Part No.	Page No.
<b>Index</b>					
Part Numbers		086660	3-3, 3-11, 3-13, 4-5, 7-7, 7-13, 8-3	600726	7-7
000323	5-5, 5-11			600759	3-7
000331	5-5, 6-5	100867	7-7	600767	3-7
000398	5-11	100875	7-7, 7-13	600899	2-3
005108	3-13, 8-3	105155	7-13	600900	7-7
005116	7-5, 7-11	107633	3-3	600901	7-7, 7-13
015495	7-15	107654	1-1	600965	3-3
015511	4-5	107696	1-1	600970	3-9
015818	5-5, 5-11	108588	3-13	600972	3-9
016253	5-3	108598	3-13	600974	3-9
016832	3-11, 5-11	110014	3-11	600975	3-9
016972	3-5	110370	3-11	600976	3-9
017129	8-3	111079	3-5	600981	3-11
017616	3-5, 7-17	111616	3-3	601069	6-3, 7-3, 7-9
019521	4-5	111617	3-3	601098	6-5
023317	8-7	112877	7-7, 7-13	601118	3-7
023655	3-11, 3-13, 4-3, 4-5	113946	5-3	601162	3-3
024927	3-13, 6-3	114052	6-5	601196	3-3
025007	3-3, 7-5, 7-11	114191	1-1	601197	3-3
025296	4-3, 7-15	114433	7-5, 7-11	601201	3-13
028118	3-3, 7-5, 7-11	114628	3-13	601211	3-13
029868	6-3	114629	3-13	601212	6-3
029876	3-11, 5-3	114631	5-9	601219	3-7
031997	4-3, 7-5, 7-11	114641	8-3	601221	3-9
034272	3-3, 3-11, 5-3, 7-5, 7-11, 7-15, 8-3	114645	7-3	601398	3-5
034280	3-11, 7-5, 7-7, 7-11, 7-13, 8-3	114648	5-3	601421	2-3
036236	5-3, 5-11, 8-3	114860	5-9	601425	3-11
036244	5-9, 7-3, 8-3	114861	5-9	601426	3-11
036384	3-5, 7-5, 7-11	114974	3-3	601434	7-5, 7-11
041988	3-3	259812	7-5, 7-11	601470	8-7
043570	8-3	322974	7-5, 7-11	601471	8-7
045898	6-5	334045	7-15	601474	3-7
047456	5-11	344267	4-3	601503	3-3
052860	5-9	347443	7-5, 7-11	601527	5-14
053199	4-3, 7-5, 7-11	348284	7-15	601624	7-3, 7-9
054502	3-11, 7-3, 7-5, 7-11	348318	7-15	601635	8-7
055749	7-15	348417	6-3	601806	7-7, 7-13
055822	5-13	348458	7-15	601815	8-3
055939	3-7, 3-13, 6-3	360131	7-15	601822	3-13
055947	6-5	366625	4-3	601824	7-7, 7-13
058776	7-5, 7-11	550446	6-5	601837	7-3, 7-9
058842	3-13	550956	7-3	601843	7-7, 7-13
059832	6-5	550957	7-9	601892	7-3, 7-9
061077	4-3	551085	2-3	601941	3-9
061101	4-3	551086	2-3	601967	2-3
061572	3-13	551087	2-5	601983	3-5
063198	3-13	551088	8-3	601986	2-5
068478	5-6	600213	1-1	601993	2-3
068551	3-3, 3-13	600221	3-11	602025	3-5
077859	8-7	600296	7-5, 7-11	602026	3-5
080655	3-11, 8-3	600684	4-5	602041	2-3
		600692	4-5	602253	3-3
		600700	4-5	602407	2-3
		600718	4-5	602468	6-5

Part No.	Page No.	Part No.	Page No.	Part No.	Page No.
602580	5-3	714618	6-3	784223	4-3
602581	5-6	720516	5-3	784439	3-11
602647	8-7	721910	8-7	784488	7-15
602680	5-3	727172	2-3	784603	4-3
602916	5-13	744276	5-3	785139	2-3
602999	5-3	745059	5-13	785154	2-3
603024	5-11	747402	4-5	785220	2-3
603025	5-11	754101	8-3	785295	5-14
603057	7-5, 7-11	754358	8-3	785485	2-5
603088	5-13	756270	7-15	785659	5-3
603089	5-13	761726	5-6	785808	6-5
603101	8-3	765339	3-13	786061	4-3
603112	5-5	767954	3-3, 3-11, 3-13, 5-3,	786079	4-5
603158	5-14		5-9, 5-13, 7-3, 7-5,	786103	4-5
603161	5-14		7-7, 7-11, 7-13, 8-3	786657	6-5
603255	5-3	767962	4-3, 7-5, 7-11, 7-15,	786731	4-3
603289	5-3, 6-3		8-7	786848	3-5
603326	5-5	768515	3-3, 3-13, 6-5	787713	3-7
603334	6-5	768523	3-3, 3-11, 3-13, 5-3,	788166	4-3, 7-5, 7-11
603476	3-7		5-11, 6-3, 7-5, 7-7,	791251	5-3
603477	3-11		7-11, 7-13, 8-3	791848	2-3
603478	3-11	769166	6-5	792226	8-3
603483	3-11	771428	6-3	793273	8-5
603484	3-11	776476	6-5	793315	8-5
603485	3-13	778365	6-5	793513	7-3
603486	3-3	781153	3-11	793521	7-9
603489	8-3	781211	3-13	793851	8-3
603519	1-1	781229	7-15	793893	7-13
603542	2-3	781294	7-15	794503	7-9
603545k	5-3	781567	3-5, 4-3, 7-5, 7-11,	794644	3-7, 6-3
603548	7-3, 7-9		7-17	796219	5-3
603617	3-3	781583	3-13	796524	5-5
603696	8-7	781708	4-3, 7-5, 7-11	796656	7-5, 7-11
704635	8-3	781831	7-15	796664	7-5
704643	7-15	781856	7-5, 7-11	797365	7-5, 7-11
704932	6-5	781872	7-5, 7-7, 7-11, 7-13	797456	8-5
705178	3-11	781880	2-5, 5-13	797464	8-5
705954	4-3	781922	3-11	797472	8-5
706531	5-3	782474	7-5, 7-7, 7-11, 7-13	797480	8-5
710087	3-3	782995	7-15	808485	2-3
712257	6-5	783506	7-5, 7-11	808493	2-3, 5-9
712372	5-3	783910	8-3	930818	1-1
712976	4-3	784199	7-5, 7-11	930826	1-1